



## FRONT PANEL

1. MC1 input loading display and buttons
2. MC2 input loading display and buttons
3. MM1 input loading display and buttons
4. MM2 input loading display and buttons
5. Input selector
6. Gain display and buttons
7. MM capacitance display and buttons
8. EQ curve selector

## REAR PANEL

1. Single-Ended/Balanced (RCA/XLR) switch
2. XLR outputs (to preamp)
3. XLR inputs (to turntables/tonearms)
4. Ground connector
5. Phonostage DC input
6. Power regulator base DC output
7. RCA inputs
8. Power regulator base DC input

## TRANSFORMER

1. Power switch
2. Fuse holder
3. IEC AC cord connection
4. DC output to power regulator base (rear of transformer)

